

Hi Paige; Just finished the install on my F700gs. This was easier than I thought. In addition to the BMW Windshield Brackets only 3 other parts were needed and available at ACE Hardware. Photos below. Here is the parts list:

- 1) BMW Bracket Kit pn: 773 8 531 603 (about \$65.00)
- 2) Ace Hardware: Chrome Steel Spacer 1/4" x 3/3"L (two thus)
- 3) Ace Hardware: Hex cap screws 1/4 - 20 1-1/2 (two thus)

The windshield support is very solid.



I only used the brackets, not the other pieces.





Ace Hardware

$\frac{1}{4}$ " x  $\frac{3}{4}$ " L  
chrome steel  
spacer



$\frac{1}{4}$ -20  $1\frac{1}{2}$ "  
Hex cap





